

WATER SOFTENER STEP-BY-STEP INSTALLATION INSTRUCTIONS

1) COMPLETE WATER SUPPLY PIPING TO THE FILTER AND WATER SOFTENER FOLLOWING THE DIAGRAM.

2) WHILE LEAVING THE WATER SOFTENER IN BYPASS, SLOWLY FILL THE FILTER WITH WATER WHILE ALLOWING AIR TO BLEED OUT OF THE HOSE BIB. ALLOW A COUPLE GALLONS OF WATER TO COME OUT. THE WATER WILL BE BLACK.

3) PUT THE WATER SOFTENER IN SERVICE. FILL WITH WATER USING THE SAME PROCEDURE EXPLAINED IN 2) ABOVE.

4) WITH THE TANKS NOW FULL, COMPLETE THE BACKWASH PIPING.

5) ONCE THE BACKWASH PIPING IS COMPLETE, RUN A MANUAL BACKWASH OF THE FILTER. THIS SHOULD TAKE 12 MINUTES.

6) ONCE THE FILTER HAS BACKWASHED, PUT 2 TO 2 1/2 GALLONS OF WATER IN THE BRINE TANK WITHOUT SALT. THE 3/8" POLY TUBING SHOULD BE INSTALLED IN THE PUSH CONNECT FITTING BEHIND THE CONTROL HEAD. IT GOES INTO THE HOLE ABOVE THE WHITE OVERFLOW ELBOW INTO THE PUSH CONNECT FITTING INSIDE THE BRINE TANK.

7) NOW RUN A MANUAL BACKWASH OF THE WATER SOFTENER, WHICH SHOULD TAKE ABOUT 40 MINUTES.

8) ADD SALT TO THE BRINE TANK AND OPEN THE WATER VALVE TO THE HOME.

***NOTE: THE WATER LEVEL SHOULD NEVER BE ABOVE THE SALT LEVEL.**